



# INSTALLATION INSTRUCTIONS

## PLEASE KEEP FOR CUSTOMER REFERENCE

For warranty purposes, a qualified tradesperson must install the vanity unit, tall boy or mirror cabinet. Please read the instructions before installation. Also check for any further instructions attached to the cabinet, top or packaging.

- Please check the vanity unit for any damage before installing. **If there is any damage, DO NOT continue with the installation.** Please contact the merchant where the vanity was purchased. Installation of the vanity unit is deemed as accepting the condition of the vanity unit.
- **If tiling, ALWAYS tile the area first before installing the vanity.** The vanity and top must sit in front of the tiling. If you tile around the vanity or top the warranty will be void.
- When using silicone, always use bathroom grade silicone with a mould inhibitor.
- Unscrew all handles from doors and drawers from the inside of the cabinet and re-install on the outside of the cabinet.
- Mark the base and back of the vanity for drilling for plumbing purposes. Check for water points, power and waste pipe positions.
- Drill holes for pipes with appropriate sized holesaws.
- **When installing the waste to the top, DO NOT OVER TIGHTEN** as this may cause damage to the top and it will not be covered by warranty. Make sure there is adequate silicone between the top and the waste and also around the waste unit under the top to seal the waste properly.
- Vanity top is to be secured in with an unbroken bead of silicone on all surfaces between the cabinet and the top. For glass tops use silicone only where it will be covered by the basin to ensure that it is not visible through the glass.
- All units must be installed level to ensure the gaps of doors and drawers are equal.
- Uneven gaps between the doors can be caused during transportation. If this occurs, door adjustments may be required. Simply use a Phillips head screw driver to adjust the hinge by turning clockwise. Please note to make one adjustment at a time and not to over tighten.
- **All edges where the vanity cabinet and top meet the wall and floor must be properly sealed with silicone. The vanity must be sealed to prevent water penetration. Materials used in the cabinet are water resistant and not water proof. IF there are any water spillages, immediately wipe dry to prevent water damage. WATER DAMAGE IS NOT COVERED BY WARRANTY.**

## PRODUCT CARE AND MAINTENANCE

Maintenance of the finish of your Greens Bathroom range is important. Here are a few simple tips to follow:

### Vanity Cabinets

For cleaning all vanity cabinets, please use a small amount of warm soapy water with a soft clean cloth, then wipe dry immediately with a soft cloth or Chamois. DO NOT let any water sit as materials used in the cabinet are water resistant but not water proof. Warranty does not cover any water damage to the cabinet. Excess moisture can only damage the cabinet so please keep the room ventilated.

### Benchtops

#### **Polymarble, Acrylic, Vitreous China, Caesarstone, RF Stone, & Corian**

Please use warm soapy water for day to day cleaning, then wipe dry immediately with a soft cloth or Chamois. For stubborn stains, use only non-abrasive cleaners available from most bathroom supply stores. Do not use abrasive cleaning agents containing a corrosive acid or scouring agent, as well as cream cleaners as they may damage the surface which is not covered under warranty.

### Timber Tops

Clean up spills straightaway. Any splashes of water around the basin on the vanity need to be mopped up with a towel. Please use warm soapy water for day to day cleaning, then wipe dry immediately with a soft cloth or Chamois.

Do not use abrasive cleaning agents containing a corrosive acid or scouring agent, as well as cream cleaners as they may damage the surface which is not covered under warranty.