

Hose And Roses:

1. Install hose and ensure sealing washers are in place.
 - a. Nut end to lower outlet on rail and tapered end to the hand set.
2. Install over head rose to rail and hand set to hose and ensure sealing washer is in place.

Diverter Operation:


1. The diverter is a manual operation turn handle either to the left or to the right.
2. **NOTE: This is not a shut off valve, must always shut off at mixer after use.**



ROCCO TWIN RAIL SHOWER R3064 INSTALLATION INSTRUCTIONS

PRODUCT #

BATCH #



Please contact country of purchase.

NZ


Distributed by: Greens Global Limited
PO Box 5055, Hamilton, 3200
22 The Boulevard, Te Rapa, Hamilton 3200
Phone: 07 849 0109, Fax: 07 849 0540
Website: www.greenstapware.com
Email: nzsales@greenstapware.com
Service Hotline: 0800 655 455

Distributed by: Greens Global AUS PTY LTD

36 Naxos Way, Keysborough VIC 3173
Phone: 1800 244 487 Fax: 1800 244 212
Email: aussales@greenstapware.com
Website: www.greenstapware.com
Service Hotline: 1800 244 992

Technical Data

- **Suitable for use with high pressure water supply only.**
Not suitable for gravity-fed water heaters, low and unequal pressure networks.
- Minimum Water pressure: 150kpa.
- Maximum water pressure: 500kpa.
- Pressure over 500kpa will require a limiting valve.
- Installation shall be in accordance with the AS/NZS3500 series of standards.
- Flow rate of 3 star 9 l/m has been rated under the Australian & NZ Water Efficiency Labeling Scheme (WELS).



- **Top Inlet at the diverter.**
- **Diverter trim ring is 60mm dia.**
- **Bottom bracket mount is adjustable with MAX 640mm Centres.**

Install The 15mm Female Inlet Adaptor:

- At pipe-out stage install a **brass 15mm male wingback elbow** (not supplied).
 - Remove the adaptor from the diverter.
 - NOTE:** Loosen off the 2 grub screws to ensure the O-rings are not cut on the adaptor.
 - Note: The female inlet adaptor requires **MAX 10mm thread** protruding from the **finished wall**.
 - Inlet is at the top.**
 - Check the height** required with customer as there is no height adjustment.
- Cut the inlet thread, to **MAX 10mm thread** from finished wall.
- Sealant required around the 15mm male thread to finished wall to ensure water tight seal** (not supplied).
- Install adaptor using a spanner or a 10mm Allen key.
 - Back edge of the adaptor to be level with the finished wall as shown.**

Install Mounting Block For Bottom Bracket:

- Mark out and install mounting block as shown in drawing and is inline with the inlet to ensure rail will be straight.
 - Must screw into a wooden stud or nog.
 - Wall anchor provided for masonry walls.
 - Sealant required behind mounting block** (not supplied).

Installing Rail:

- Screw rail with O-ring seal end into the diverter.
- Position bottom bracket to bottom of rail.
 - Adjust bracket height required and tighten locking screw.**
- Position **trim rings** to diverter and bracket.
- Install diverter with rail to inlet adaptor and position bracket onto mounting block.
 - Lightly grease the O-rings on the inlet adaptor.
 - CHECK:** The **grub screws** in diverter and bracket are **not projecting into the bore** to ensure seal not cut.
 - Position flanges against finished wall.
 - Tighten the grub screws** . No not overtighten.

Overhead & Arm:

- Install overhead arm to top of diverter, position and tighten the nut.