



INSTALLATION INSTRUCTIONS

- **Top Inlet at the diverter.**
- **Diverter size is 35mm x 35mm.**
- **Bottom bracket mount is adjustable with max 800mm Centres.**

Install The 15mm Female Inlet Adaptor:

1. At pipe-out stage install a **brass 15mm male wingback elbow** (not supplied).
 - a. Remove the adaptor from the diverter.
 - i. **NOTE:** Loosen off the grub screw to ensure the O-rings are not cut on the adaptor.
 - b. Note: The female inlet adaptor requires MAX 20mm thread from finished wall.
 - c. **Inlet is at the top.**
 - d. **CHECK: The height required with customer** as there is no height adjustment.
2. Cut the inlet thread to **MAX 20mm** from finished wall.
3. Install adaptor using a spanner or a 10mm Allen key.
 - a. **Back edge of the adaptor to be level with the finished wall as shown.**

Install Mounting Sleeve For Bottom Bracket:

1. Mark out and install mounting block as shown in drawing in line with the inlet to ensure rail will be straight.
 - a. **Note:** For adjusting the bracket height, back off the locking screws inside bracket and retighten.
 - b. Must screw into a wooden stud or nog.
 - c. Wall anchor provided for masonry walls.

Installing Rail:

1. Slide the slide control onto the lower rail.
2. **Install lower rail and top rail** to diverter and **tighten the screws.**
 - a. Lightly grease the O-rings on the diverter.
 - b. **CHECK: The screw is not projecting into the bore on the rail.**
 - i. Loosen off to ensure not to cut the O-rings on the diverter.
 - c. Check alignment of the rail.
3. **Adjust height position of the lower bracket to fit sleeve.**
 - a. Back off the adjusting locking screws inside brackets and **retighten.**
4. Install rail to inlet adaptor and mounting sleeve.
 - a. **Tighten the grub screws** with Allen key to secure rail to mounts.
 - b. Sealant is required behind wall brackets for water seal (not supplied).